





TPE 331 Parts



PART NO.	PART DESCRIPTION	AIRCRAFT OR ENGINE	CONDITION
3101373-1HP	Lock Plate	TPE331	NEW
3101703-10HP	Bushing	TPE331	NEW
3101703-11 HP	Bushing	TPE331	NEW
3101703-12HP	Bushing	TPE331	NEW
3101703-13HP	Bushing	TPE331	NEW
3101703-14HP	Bushing	TPE331	NEW
3101703-15HP	Bushing	TPE331	NEW
3101703-16HP	Bushing	TPE331	NEW
3101703-17HP	Bushing	TPE331	NEW
3101703-18HP	Bushing	TPE331	NEW
3101703-19HP	Bushing	TPE331	NEW
3101703-1HP	Bushing	TPE331	NEW
3101703-20HP	Bushing	TPE331	NEW



TPE 331 Parts




PART NO.	PART DESCRIPTION	AIRCRAFT OR ENGINE	CONDITION
3101703-24HP	Bushing	TPE331	NEW
3101703-25HP	Bushing	TPE331	NEW
3101703-26HP	Bushing	TPE331	NEW
3101703-27HP	Bushing	TPE331	NEW
3101703-28HP	Bushing	TPE331	NEW
3101703-29HP	Bushing	TPE331	NEW
3101703-2HP	Bushing	TPE331	NEW
3101703-3HP	Bushing	TPE331	NEW
3101703-4HP	Bushing	TPE331	NEW
3101703-5HP	Bushing	TPE331	NEW
3101703-6HP	Bushing	TPE331	NEW
3101703-7HP	Bushing	TPE331	NEW
3101703-8HP	Bushing	TPE331	NEW



TPE 331 Parts



PART NO.	PART DESCRIPTION	AIRCRAFT OR ENGINE	CONDITION
3101703-9HP	Bushing	TPE331	NEW
3101759-1HP	Bushing	TPE331	NEW
3101759-2HP	Bushing	TPE331	NEW
3101759-3HP	Bushing	TPE331	NEW
3101759-4HP	Bushing	TPE331	NEW
3101759-5HP	Bushing	TPE331	NEW
3101759-6HP	Bushing	TPE331	NEW
3101759-7HP	Bushing	TPE331	NEW
865057-7HP	Retainer	TPE331	NEW
865542-5HP	Bearing Sleeve	TPE331	NEW
867595-3HP	Gasket	TPE331	NEW
867681-5HP	Seal Disk	TPE331	NEW
867905-1HP	Valve Seat	TPE331	NEW



PART NO.	PART DESCRIPTION	AIRCRAFT OR ENGINE	CONDITION
868746-6HP	Gasket	TPE331	NEW
869615-1HP	Bearing Sleeve	TPE331	NEW
869615-2HP	Bearing Sleeve	TPE331	NEW
869616-1HP	Bearing Sleeve	TPE331	NEW
869616-2HP	Bearing Sleeve	TPE331	NEW
893579-1HP	Bushing	TPE331	NEW